## **DEPARTURE/PENETRATION POSITION/JOIN**

East Midlands	
Ground/ Control,	Eurostar G-CCMO, request
OR ATSU for LARS	transit OR MATZ Penetration
OR 71100 101 271110	OR Request lower airspace
	radar service OR request
"Pass your	crossing of airway
message"	at
Current position	
Departure point	
_	
<b>H</b> eading	
Altitude/FL and	
pressure	
<u>-</u>	VED
<mark>V</mark> FR	VFR
En rout to ETAbound	
Reqst; Transit SVFR	
Penetration etc	
if SVFR, eta at zone	0.0040
boundary is required	G-CCMO
Advise when leaving	"East Midlands, G-CCMO
<b>5</b>	request change to
Call on leaving area	. on
+If Asked for position	G-CCMO
<b>P</b> osition	
<b>A</b> ltitude	
Time (mins only)	
Next reporting point	
ETA for nxt rep point	
"East Midlands Control	G-CCMO
Position	
Height	
request join for one visual circuit"	